




INSTALLATION INSTRUCTIONS
CAT-BACK DUAL REAR MUFFLER REPLACEMENT
05-06 FORD MUSTANG GT 4.6L V8
PART # 319001



ITEM	PART #	QUANTITY	DESCRIPTION
A	700801	1	2½" Driver Muffler assembly w/welded stainless tip
B	700802	1	2½" Passenger Muffler assembly w/welded stainless tip
C	5757	2	2½" Clamp

Thank you for purchasing our Gibson exhaust system for your vehicle. If you need further assistance, please do not hesitate to call our technical dept at (800) 528-3044 Monday through Friday, 8:00 am to 5:00 pm. 0906

INSTALLATION INSTRUCTIONS # 319001

CAREFULLY READ INSTRUCTIONS BEFORE STARTING INSTALLATION.

When installing this exhaust system make sure to use proper safety precautions. Use jack stands when working under the vehicle, set parking brake, block tires and use safety glasses and gloves. Allow exhaust to cool before attempting installation. Severe injury or burns could occur if safety measures are not taken.

SUGGESTED TOOLS: 9/16" 15mm wrenches & sockets, WD-40. 13 mm socket & wrench.

.....
Disconnect the negative battery cable before removal of OEM exhaust. This will allow the computer to reset and recognize the new exhaust. Lay out the exhaust on the floor so it looks like the drawing and compare parts with manual.
.....



1. Remove your stock muffler assemblies from the clamps located in front of your stock mufflers. Then remove both rubber grommets from each side. For easier removal, using a 13mm wrench or socket.



2. Install muffler assemblies #A and #B onto factory pipe, use clamp #C to secure. Insert welded hangers into rubber grommets. DO NOT TIGHTEN.



3. When you have everything in place, firmly tighten all bolts and clamps down securely. Use stainless steel cleaner and a Scotch Brite pad weekly to prevent tip from discoloration.

GIBSON EXHAUST systems are designed on a factory stock vehicle. Any aftermarket products installed could increase the sound levels of this Exhaust. **Make sure there is a 1" clearance from ALL rubber brake lines, shock boots, fuel lines, tires, etc to prevent heat related damage or fire.**